

**Test plan
KIRK handset on foreign DECT systems.**

| | | | | | | | | |
|------------------------|----|---|------|------------|------|-----|--|-------------|
| KIRK telecom | ED | 1 | DATE | 2004-06-11 | SIGN | kmn | | Page 1 of 4 |
| KIRK HANDSET | | | | | | | | |

Test plan KIRK handset on foreign DECT systems.

1 TEST CONDITION:

| | | |
|--|------------------------|--|
| Handset | Type: | |
| | Hardware PCS: | |
| | Soft ware PCS: | |
| | | |
| PBX | Brand: | |
| | Type: | |
| | Soft ware Ver.: | |
| | Hard ware Ver.: | |
| | | |
| TEST ACTIVITY. | | |
| A, B and C = Handset, X and Y = System Phones or Analogue | | |
| | | |

Subscription / Registration of Handset on the system.

Please describe the procedure here:

1.1 Basic Call and CLIP.

Priority: Major 1 – Minor 2 – Further 3.

| Test step | Description | Expected result, or Pass / fail criteria | Actual Result ("Pass"/"fail") | Priority |
|------------------|----------------------|---|--------------------------------------|-----------------|
| 1 | A Off Hook | Dial tone | | |
| 2 | Call B | Ring Back tone at A – B Ringing + CLIP | | |
| 3 | B Off Hook | Audio Rx/Tx | | |
| 4 | B On Hook | Busy Tone at A | | |
| 5 | A On Hook | Call released. | | |
| 6 | | | | |
| 7 | A Call B | B Don't answer | | |
| 8 | A On Hook | Ring stop at B | | |
| 9 | Call release. | | | |
| 10 | | | | |
| 11 | A Off Hook | Dial tone | | |
| 12 | Call X | Ring Back tone at A – X Ringing + CLIP | | |
| 13 | X Off Hook | Audio Rx/Tx | | |
| 14 | X On Hook | Busy Tone at A | | |
| 15 | A On Hook | Call released. | | |
| 16 | | | | |
| 17 | A Off Hook | Dial tone | | |
| 18 | Call X | Ring Back tone at A – X Ringing + CLIP | | |

Test plan KIRK handset on foreign DECT systems.

| | | | | |
|----|--|-----------------------|--|--|
| 19 | X Off Hook | Audio Rx/Tx | | |
| 20 | Press a number of digits | DTMF Tones in X | | |
| 21 | A On Hook | X On Hook | | |
| 22 | | Call released. | | |
| 23 | Repeat step 17-22 with an analogue phone as X. | | | |
| 24 | | | | |
| 25 | A Call X | X Don't answer | | |
| 26 | A On Hook | Ring stop X | | |
| 27 | | Call released. | | |
| 28 | | | | |
| 29 | Incoming Call to A | A Ringing + CLIP | | |
| 30 | A Off Hook | Audio Rx/Tx | | |
| 31 | A On Hook | Call released. | | |
| 32 | | | | |
| 33 | A On Hook Dialling B | B Ringing + CLIP | | |
| 34 | Call release | | | |
| 35 | | | | |

1.2 Call Transfer.

| Test step | Description | Expected result, or Pass / fail criteria | Actual Result ("Pass"/"fail") | Priority |
|-----------|---|--|-------------------------------|----------|
| 36 | A Off Hook | Dial tone | | |
| 37 | Call B | Ring Back tone at A – B Ringing + CLIP | | |
| 38 | B Off Hook | Audio Rx/Tx | | |
| 39 | B Press R (On Hold) | Dial Tone at B | | |
| 40 | Call C | C Ringing + CLIP from B | | |
| 41 | C Off Hook | Audio Rx/Tx | | |
| 42 | B On Hook (Call Transfer) | C CLIP from A + Audio Rx/Tx | | |
| 43 | Call release | | | |
| 44 | 36-43 Testes as ECT and BCT (Explicit and Blind Transfer) | | | |
| 45 | | | | |
| 46 | A Off Hook | Dial tone | | |
| 47 | Call X | Ring Back tone at A – X Ringing + CLIP | | |
| 48 | X Off Hook | Audio Rx/Tx | | |
| 49 | X Press R (On Hold) | Dial Tone at X | | |
| 50 | Call C | C Ringing + CLIP from X | | |
| 51 | C Off Hook | Audio Rx/Tx | | |
| 52 | X On Hook (Call Transfer) | C CLIP from A + Audio Rx/Tx | | |
| 53 | Call release | | | |
| 54 | 46-53 Testes as ECT and BCT (Explicit and Blind Transfer) | | | |
| 55 | | | | |
| 56 | A Off Hook | Dial tone | | |
| 57 | Call X | Ring Back tone at A – X Ringing + CLIP | | |
| 58 | X Off Hook | Audio Rx/Tx | | |
| 59 | X Press R (On Hold) | Dial Tone at X | | |
| 60 | Call Y | Y Ringing + CLIP from X | | |
| 61 | Y Off Hook | Audio Rx/Tx | | |
| 62 | X On Hook (Call Transfer) | Y CLIP from A + Audio Rx/Tx | | |
| 63 | Call release | | | |

Test plan KIRK handset on foreign DECT systems.

| | | | | |
|----|--|--|--|--|
| 64 | | | | |
|----|--|--|--|--|

1.3 Handover test.

| Test step | Description | Expected result, or Pass / fail criteria | Actual Result ("Pass"/"fail") | Priority |
|-----------|----------------------|--|-------------------------------|----------|
| 65 | Press *99989* √ on A | Test mode | | |
| 66 | A Off Hook | Dial Tone | | |
| 67 | Call B | Audio Rx/Tx | | |
| 68 | Press <MENU> * | Check Connection Handover and Audio Rx/Tx. | | |
| 69 | Press <MENU> # | Check Bearer Handover all frequency and Time slot and Audio Rx/Tx. | | |

1.4 Comments.